

Vintage Control Panel



Volume 1

(nearest the treble / bridge pickup): Controls the volume for the treble or bridge position pickup.

Volume 2

(nearest the bass / neck pickup): Controls the volume for the bass or neck position pickup.

Rhythm/Solo Switch:

Boosts the overall volume of the bass when in the solo position.

Bass On:

Turns off the treble / bridge pickup and produces bass boost.

Treble On:

Turns off the bass / neck pickup and produces treble boost.

NB.

There will be NO SOUND if both the treble and bass switches are in the ON position. To hear both pickups simultaneously make sure both volume controls are all the way up in FULL ON position and both treble and bass switches are in the OFF position.